

Bedienungsanleitung

Ferngesteuerte Kerzen McShine „Candle 12“

Einführung

Geehrter Kunde,
wir möchten Ihnen zum Erwerb Ihrer
neuen Kerzen gratulieren!

Mit dieser Wahl haben Sie sich für ein Produkt
entschieden, welches ansprechendes Design
und durchdachte technische Features gekonnt
vereint.

Lesen Sie bitte die folgenden Bedienungshinweise
sorgfältig durch und befolgen Sie diese, um in
möglichst ungetrübten Genuss des Gerätes zu
kommen!



Leistungsmerkmale:

Die ferngesteuerten Kerzen verleihen zu jeder
Gelegenheit ein festliches Ambiente, egal ob als
Weihnachts – oder Partyschmuck.
Einfach aufstellen oder festklemmen.

Technische Daten:

Gewicht: 19.8 g (Kerze), 31.5 g (-988)
Maße: 100*19 mm (Kerze), 90*35*20 mm (-988)
Lampen: 10 (LED)
Betrieb: 1.5 V (AA) (Kerze), 2x 1.5V V (AAA) (-988)
Nennstrom: max. 20 mA
Arbeitsdauer: min. 180 h
Fernbedienung: Infrarot (IR)
Reichweite: max. 15 m
Code:
(-987): Komplettsset
(-988): Ersatzfernbedienung
(-989): Ersatzlampe

Sicherheitshinweise

Überprüfen Sie vor Inbetriebnahme die Kerzen auf Beschädigungen, sollte dies der Fall sein, bitte diese
nicht in Betrieb nehmen!

Die Kerzen sind für den Innenbereich konzipiert.

Zwischen Fernbedienung und Kerzen muß freies Sichtfeld herrschen.

Den Kerzenbogen keine mechanischen Belastungen, hohen Temperaturen oder Feuchtigkeit
aussetzen.

Reinigen Sie den Kerzenbogen mit einem weichen trockenen Tuch.

Wichtig! Sollten das Gerät einmal beschädigt werden, lassen Sie es nur durch den Hersteller oder eine
Fachwerkstatt instandsetzen.

Lassen Sie das Verpackungsmaterial nicht achtlos liegen, Plastikfolien / -tüten, Styroportteile, etc.,
könnten für Kinder zu einem gefährlichen Spielzeug werden.

Die Geräte gehören nicht in Kinderhände. Sie sind kein Spielzeug.

Teile und Funktionen:

1. LED-Lampe.
2. Kerzenkörper inklusive Batteriefach.
3. Deckel des Batteriefaches.
4. Verschluss des Batteriefaches.
5. Fernbedienung.
6. IR-Leuchtdiode (Sender).
7. ON: Einschalter.
8. OFF: Ausschalter.
9. Leuchtdiode als Betriebsanzeige.
10. Klammer.
11. Kerzenhalter.

Betrieb:

Setzen Sie die Batterien in die Kerzen und in die Fernbedienung ein.

Jetzt kann mit der Fernbedienung die Kerzen ein (ON) oder ausschalten (OFF).

Die Kerzen selbst kann man entweder einfach ausstellen oder mit Hilfe de Klemmen am gewünschten Ort befestigen.



Reference Manual

Remote-controlled Candles McShine "Candle 12"

Preface

Dear Customer,
we like to congratulate you on the
purchase of your new candles!

You have chosen a product which
combines deliberate technical features
with an appealing design.

Please read this manual conscientiously
and carry out the given instructions before
and while you are using your new device.



Capability Characteristics

This remote-controlled candles illuminate every
environment with a pleasant light for instance as
Christmas or party decoration.
For simply setting up or wedging.

Technical Specifications:

Weight: 19.8 g (Candle), 31.5 g (-988)
Size: 100*19 mm (Candle), 90*35*20 mm (-988)
Lamps: 10 (LED)
Operation: 1.5 V (AA) (Candle), 2x 1.5 V (AAA) (-
988)
Rated Current: max. 20 mA
Working Duration: min. 180 h
Remote Control: Infrarot (IR)
Range: max. 15 m
Code:
(-987): Complete set
(-988): Replacement remote control
(-989): Replacement lamp

Security Advices

Before using the device, please check it for any possible damages. In case of damage do not operate it.
For indoor use only.

Between the remote control and the candles must be a free field of view.

The device may not become subject of mechanical stress and should not be exposed to humidity or high
temperature.

Clean the device with a dry and soft cloth only.

Caution! Should the device itself get damaged, please let the repair to the manufacturer or to a qualified
service agent.

Please dispose packaging materials properly and do not let play children with it.

The device itself is no toy either. Do not let children play with it too.

Parts and Functions:

1. LED-lamp.
2. Candle body including battery compartment.
3. Battery compartment cover.
4. Cover of the battery compartment.
5. Remote control.
6. IR-light emitting diode (Transmitter).
7. ON: On-switch.
8. OFF: Off-switch.
9. LED as operation display.
10. Clamp.
11. Candle holder.

Operation:

Insert the batteries into the candles and the remote control.

Now use the remote control to switch the candles on (ON) or off (OFF).

The candles can be simply set up or mounted to the desired place with help of the clamps.

