



ASSEMBLY INSTRUCTION

NYS 373-* | Heavy duty Phono Plug

A Slide the boot onto the cable.

B Prepare cable as shown.

C Solder the wire ends.

D Position the chuck onto the cable and align chuck with plugfinger.

E Slide the housing onto the Plugfinger with chuck.

F Finish the installation by tighten the bushing onto the connector.

Attention: If using a cable with big O.D. break off marked part on the chuck.

6.0 mm [0.24"]

8.0 mm [0.32"]

3.0 mm [0.12"]

break off

| | | | | | | | |
|------------------------|-------------|-----------------------|-----------------------|------------------------|----|----------------------|----------------------|
| NEUTRIK AG | LI | T: +423 / 237 24 24 | F: +423 / 232 53 93 | NEUTRIK France | FR | T: +33 1 / 4131 6750 | F: +33 1 / 4131 0511 |
| NEUTRIK USA Inc. | USA | T: +1 732 / 901 9488 | F: +1 732 / 901 9608 | NEUTRIK Tokyo Ltd. | JP | T: +81 3 / 3663 4733 | F: +81 3 / 3663 4796 |
| NEUTRIK (UK) Ltd. | UK | T: +44 1983 / 811 441 | F: +44 1983 / 811 439 | NEUTRIK Hong Kong Ltd. | HK | T: +852 / 2687 6055 | F: +852 / 2687 6052 |
| NEUTRIK Vertriebs GmbH | DE/NL/AT/DK | T: +49 8131 / 280 890 | F: +49 8131 / 280 830 | | | | |

Draft. Nr.: BDA 262-0 / 3102M1811 | Update: 21.01..2010 | Data subject to change without prior notice. © 2010 NEUTRIK® . ALL RIGHTS RESERVED.