



mükra
e l e c t r o n i c

Kompatibel mit:

Desire	Desire, HTC Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG
Galaxy Ace (S5830)	Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG
Galaxy Ace 2 (I8160P)	Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG
Galaxy Ace 3 (S7275)	Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG
Galaxy Ace Duos (S6802)	Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG
Galaxy Express (i8730)	Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG
Galaxy Gio (S5660)	Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S

Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG

Galaxy Mega (I9205) Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG

Galaxy Mini (S5570i) Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG

Galaxy Note (N7000) Galaxy Note (N7000), Galaxy Note 2 (N7100), Galaxy Note 3 (N9005), SAMSUNG

Galaxy Note 2 (N7100) Galaxy Note (N7000), Galaxy Note 2 (N7100), Galaxy Note 3 (N9005), SAMSUNG

Galaxy Note 3 (N9005) Galaxy Note (N7000), Galaxy Note 2 (N7100), Galaxy Note 3 (N9005), SAMSUNG

Galaxy S (i9000) Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG

Galaxy S Advance (I9070) Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG

Galaxy S Duos (S6802) Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S

Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG

Galaxy S Plus (I9001)
Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG

GALAXY S2 (I9100)
Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG

GALAXY S3 (I9300)
Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG

Galaxy S3 mini (I8190)
Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG

GALAXY S4 (I9500)
Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG

	Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG
Galaxy Tab 3 10.1 (P5200)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
Galaxy Tab 3 10.1 (P5210)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
Galaxy Tab 3 10.1 (P5220)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
Galaxy Tab 3 7.0 (T210)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
Galaxy Tab 3 7.0 (T211)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
Galaxy Tab 3 8.0 (T310)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
Galaxy Tab 3 8.0 (T311)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
Galaxy Tab 3 8.0 (T315)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
GALAXY TAB 4 10.0 (SM-T530)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
GALAXY TAB 4 7.0 (SM-T230)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
GALAXY TAB 4 8.0 (SM-T335)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
GALAXY TAB Pro 10.1 (SM-T525)	Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG
Galaxy Y (S5360)	Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001), GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190), GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295), Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500), Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310), SAMSUNG
Galaxy Young (S6310)	Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275), Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660), Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S

Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001),
 GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190),
 GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295),
 Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500),
 Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310),
 SAMSUNG
 HTC
 Desire, HTC
 HTC, ONE (M7)
 HTC, ONE MINI (M4)
 Lumia 1520 Lumia 1520, Lumia 520, Lumia 610, Lumia 620, Lumia 630, Lumia 710,
 Lumia 800, Lumia 820, Lumia 910, Lumia 925, NOKIA
 Lumia 520 Lumia 1520, Lumia 520, Lumia 610, Lumia 620, Lumia 630, Lumia 710,
 Lumia 800, Lumia 820, Lumia 910, Lumia 925, NOKIA
 Lumia 610 Lumia 1520, Lumia 520, Lumia 610, Lumia 620, Lumia 630, Lumia 710,
 Lumia 800, Lumia 820, Lumia 910, Lumia 925, NOKIA
 Lumia 620 Lumia 1520, Lumia 520, Lumia 610, Lumia 620, Lumia 630, Lumia 710,
 Lumia 800, Lumia 820, Lumia 910, Lumia 925, NOKIA
 Lumia 630 Lumia 1520, Lumia 520, Lumia 610, Lumia 620, Lumia 630, Lumia 710,
 Lumia 800, Lumia 820, Lumia 910, Lumia 925, NOKIA
 Lumia 710 Lumia 1520, Lumia 520, Lumia 610, Lumia 620, Lumia 630, Lumia 710,
 Lumia 800, Lumia 820, Lumia 910, Lumia 925, NOKIA
 Lumia 800 Lumia 1520, Lumia 520, Lumia 610, Lumia 620, Lumia 630, Lumia 710,
 Lumia 800, Lumia 820, Lumia 910, Lumia 925, NOKIA
 Lumia 820 Lumia 1520, Lumia 520, Lumia 610, Lumia 620, Lumia 630, Lumia 710,
 Lumia 800, Lumia 820, Lumia 910, Lumia 925, NOKIA
 Lumia 910 Lumia 1520, Lumia 520, Lumia 610, Lumia 620, Lumia 630, Lumia 710,
 Lumia 800, Lumia 820, Lumia 910, Lumia 925, NOKIA
 Lumia 925 Lumia 1520, Lumia 520, Lumia 610, Lumia 620, Lumia 630, Lumia 710,
 Lumia 800, Lumia 820, Lumia 910, Lumia 925, NOKIA
 NOKIA Lumia 1520, Lumia 520, Lumia 610, Lumia 620, Lumia 630, Lumia 710,
 Lumia 800, Lumia 820, Lumia 910, Lumia 925, NOKIA
 ONE (M7) HTC, ONE (M7)
 ONE (M8) HTC, ONE (M7)
 ONE MINI (M4) HTC, ONE MINI (M4)
 ONE Mini (M5) HTC, ONE (M7)
 Raspberry Pi Raspberry Pi 2
 Galaxy Ace (S5830), Galaxy Ace 2 (I8160P), Galaxy Ace 3 (S7275),
 Galaxy Ace Duos (S6802), Galaxy Express (i8730), Galaxy Gio (S5660),
 Galaxy Mega (I9205), Galaxy Mini (S5570i), Galaxy S (i9000), Galaxy S
 Advance (I9070), Galaxy S Duos (S6802), Galaxy S Plus (I9001),
 GALAXY S2 (I9100), GALAXY S3 (I9300), Galaxy S3 mini (I8190),
 GALAXY S4 (I9500), Galaxy S4 (I9505), Galaxy S4 active (I9295),
 Galaxy S4 mini (I9190), Galaxy S4 mini (I9195), GALAXY S5 (I5500),
 Galaxy Star (S5280), Galaxy Y (S5360), Galaxy Young (S6310),
 SAMSUNG
 SAMSUNG Galaxy Note (N7000), Galaxy Note 2 (N7100), Galaxy Note 3 (N9005),
 SAMSUNG
 Galaxy Tab 3 10.1 (P5200), Galaxy Tab 3 10.1 (P5210), Galaxy Tab 3 10.1
 (P5220), Galaxy Tab 3 7.0 (T210), Galaxy Tab 3 7.0 (T211), Galaxy Tab 3
 8.0 (T310), Galaxy Tab 3 8.0 (T311), Galaxy Tab 3 8.0 (T315), SAMSUNG

